

MODEL 772CB INDOOR/OUTDOOR WIRE-IN LIGHT CONTROL-OWNERS MANUAL
FOR INSIDE USE ONLY WITH INCANDESCENT LAMP CIRCUITS OF 500 WATTS OR LESS, NOT FOR USE IN
CIRCUITS WITH FLUORESCENT LAMPS OR WITH LIGHT DIMMERS.



The Wire-in Control can be operated by remote control transmitters: Models 73, 750, 753, 756 and Series 50.

The Wire-in Control consists of two parts: the power supply and the receiver. It can replace either single pole (1 switch controlling a single light) or 3-way switches (2 switches controlling a single light). Depending on the 3-way switch wiring, light may turn on after a power failure. If properly wired, this will not occur with a single pole switch installation.

TURN OFF THE POWER TO CIRCUIT AT FUSE BOX OR CIRCUIT BREAKER BEFORE BEGINNING INSTALLATION

Figure 1 illustrates the installation of receiver and power supply to junction box in interior wall.

1. Pry up lower edge of actuator button until it separates from receiver housing. Set actuator aside.
2. Remove the 6-32"x1 1/2" screw and unplug receivers from power supply. Set receiver aside.
3. Remove wall plate and set aside for reassembly.
4. Remove screws holding switch to junction box.



5. Pull switch from the junction box in order to access the connecting terminals. On a 3-way switches mark the common terminal wire before disconnecting. (Common terminal may be marked "common", "com" - or uses a different color screw (gold or silver) than the other two terminal screws.)
6. Disconnect wires from switch. Straighten the ends and make sure that insulation is trimmed back 1/2" to allow connection of power supply wires.

Transmitter range will vary depending on your house and wiring construction. metal lath, foil-backed insulation or aluminum siding will reduce range. After installation is complete, test remote control operation at various locations within your home for convenience and range.


SINGLE POLE SWITCH: If transmission range is noticeably shorter when turning OFF than when turning light ON, reverse wiring connections.

3-WAY SWITCH: If transmission range is noticeably shorter when turning light OFF than when turning light ON, the Wire-in Control needs to be installed in the other switching location. (The black wire in the Wire-in Control must be connected to the "hot" junction box wire.)

CAUTION: If there is a ground on your switch (usually a bare attached to a green screw on switch), connect wire to the metal junction box. If box is plastic, connect wire to metal part of Wire-in Control.


SINGLE POLE SWITCH

Fold the BLUE power supply wire back as shown and cap with wire nut. Screw nut in clockwise direction to secure. cap black control wire to one junction box wire and red control wire to the other. Screw wire nuts on clockwise, making sure bare wires are covered.



3-WAY SWITCH


Start by capping the black control wire to the COMMON "hot or live" wire; the red and blue control wires separately to the other two junction box wires in any order. Screw wire nuts on clockwise, making sure bare wires are covered.



7. Carefully pack the wiring back into junction box. Make sure wires are not pinched or strained.
8. Fasten power supply to junction box with the #6x1 1/2 flat-head screws provided
9. Move power supply switch to the right. Move receiver slide bar so "OFF" is visible. The control will be OFF.
10. Refer to Figure 1. Position wall plate over junction box. Align receiver so that three-pin plug engages holes in power supply and slide bar engages the power supply switch. Insert (2)#6-32x1 1/2" screws through fastening holes in receiver, wall plate and power supply.


Tighten securely.

Do not replace the actuator push button until you have set the code. See instructions below.



PROCEDURE FOR SETTING OR CHANGING THE CODE

The Wire-in Control receiver and remote control must be set with matching codes. To set (or change the code for any reason follow instructions below.) The receiver code switches are located on the front of the unit, behind actuator. The switch code block with plus (+), (0) and minus (-) positions provide 19,683 possible code settings.



WITH MULTI FUNCTION TRANSMITTER

Follow instructions packed with your multi-function transmitter.

Reassemble transmitter cover case. Snap the actuator cover onto receiver. Turn on the power to circuit. Move receiver slide bar so "ON" is visible. Control will be ON.

WITH SINGLE FUNCTION TRANSMITTER

Locate code switches in remote, either by sliding battery compartment cover back or by removing cover screw.

Set (or change) code in receiver by sliding one or more of the 9 code switches to a plus, (0) or minus position.

Hold remote control alongside receiver code switches. Set code switches in remote to match positions of receiver code switches. Reassemble remote control case. Snap actuator cover onto receiver. Turn on the power to circuit. Move receiver slide bar so "ON" is visible. Control will be ON.

11. TO TEST: press actuator push button. Light should turn on. Press again, Light should turn off. Press remote push button. Light should turn on. Press again and light should turn off.

12. If light does not operate, check to be sure:
- Power is ON. Check fuse box or circuit breaker.
 - Light bulb is "good".
 - Receiver is firmly connected to power supply and slide bar is in ON position,
 - Electrical wiring is correct. Review the wiring instructions on Side 1.
 - receiver and remote have matching code settings.
 - You are pressing the remote push button selected to operate Wire-in (on multi function transmitters),
 - Remote control battery has power.


NOTE: Test light on the remote should glow when push button is pressed. (Battery changing information is included in instructions packed with your remote control.)

CAUTION: TO AVOID ELECTRIC SHOCK, move the slide switch to the OFF position whenever it is necessary to change a light bulb.

IMPORTANT NOTE: If you use less than a 40 Watt bulb, the lamp may glow dimly when OFF. This is normal.

If two or more Light Products are installed, they must be located at least 10 feet apart to prevent electronic interference.

There is a selection of accessories for use with the multi function remote transmitter:



Multi Function
Remote Control
Model 753CB

Plug-In Light Control
Receiver Module
Model 774CB

Screw-In Light Control
Receiver Module
Model 771CB