

Programming instructions for OHD 451, 456, 551, 556, 656

1. On the back of the motor press the far right button labeled SC.
2. Light on the motor head will flash once.
3. Press the remote button and light will flash twice.
4. Press the remote button and the light will flash 3 times.
5. Press the remote button and the light will flash 4 times.
6. Press the remote button and the light will flash 5 times.
7. Light will go out for about 15 seconds then come back on then off.
8. Programming completed and you can test the remote.