


R893 Remote Control Instructions

Each button of the remote control is independently programmed to one of four different settings that is identified by the color of the garage door openers learn button or the type of remote used for gate openers and external radio receivers.

# Of Button Presses	Color of Learn Button or Receiver Type
1	Security+2.0 (Yellow Button)
2	Security+ 315MHz (Purple Button)
3	Security+ 390MHz (Red/Orange Button)
4	Billion Code 390MHz (Green Button)

1. Identify the setting needed for the opener or openers from the chart for the number of button presses needed to set it for that mode.
2. Slide off the access cover then press and hold the small program button until the LED flashes 4 times then release the program button.
3. Press and release the button on the remote you want to use the number of times needed from the chart then press and release the program button twice and the LED will flash to save that setting. Repeat for the other button as needed.
4. Once the remote has been set it will need to be added to the openers or receivers' memory before it will work.
5. Press and release the learn button on the opener or receiver so its indicator light comes on then press and hold down the remotes button until the indicator light goes out then release the button. Test the remote to verify it is working then repeat for the other buttons is used.



Program Button

Warranty: This remote carries a one-year manufactures warranty against defects in workmanship or materials commencing from the purchase date of the remote excluding the battery. For any assistance with this product contact:

Remotes4Less Apple Valley, CA 92307
Email: support@remotes4less.com Phone: 760-242-6838
© 2022 Remotes4Less All rights reserved
Manufactured by: Shenzhen JOS Technology Co., Ltd China